



Key to Arm/Disarm Unit

Ultra Loud 105 dB Alarm

Alarm Sounds When
Magnetic Contact Is
Separated

DOOR/WINDOW ALARM

Security Alarm



HS4310

Carlon®

1-YEAR
WARRANTY

DOOR/WINDOW ALARM

*Provides alarm security
to door, window,
sliding glass door, or
potentially dangerous
cabinet or closet.*



- Easy to install
- No wiring
- Uses 3 LR44 button cell batteries (installed)

INSTALLATION

- 1. Position alarm** on the stationary edge of the door or window frame and mount it to the frame using double-sided, pressure sensitive tape.
Note: Make sure mounting surfaces are free of dust, oil and other substances that could affect adhesion.
- 2. Mount** the magnet at the edge of the door or window, so that the magnet and the alarm arrows align with each other. Use spacers, if necessary, to bring the alarm and magnet into correct alignment.

OPERATION

- 1.** Remove key, located on top of alarm, to arm unit.
- 2.** When door or window is opened, alarm will sound.
- 3.** Insert key to disarm unit.

Carlon®

25701 Science Park Drive
Cleveland, Ohio 44122
www.lamson-sessions.com

Made in China
© 2004 LAMSON & SESSIONS
0408 SR4310



0 34481 17542 1

LIMITED WARRANTY

The product you have purchased is guaranteed against defects in workmanship and materials for the period stated on the package. Warranties implied by law are subject to the same time period limitation. Some states do not allow limitations on how long an implied warranty lasts, so this time limitation may not apply to you.

If the product fails due to a manufacturing defect during normal use, return the product and dated sales receipt to the store where purchased for replacement OR send the product and the dated sales receipt to:

**Lamson & Sessions
25701 Science Park Drive
Cleveland, OH 44122 USA
Attn: LHP Customer Service**

Not Covered - Batteries, light bulbs, and other expendable items are not covered by this warranty. Repair service, adjustment and calibration due to misuse, abuse or negligence are not covered by this warranty. Unauthorized service or modification of the product or of any furnished components will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, installation, set-up time, loss of use, postage, unauthorized service, or other products used in conjunction with, but are not supplied by, Lamson & Sessions.

All requests for replacement must include a **dated sales receipt** (copies accepted). LAMSON & SESSIONS IS NOT LIABLE FOR LOST PROFITS, INDIRECT, SPECIAL, EXEMPLARY, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING WITHOUT LIMITATION ANY SUCH DAMAGES DUE TO IMPROPER WIRING OR MISUSE OF THE PRODUCT. As some states do not allow the exclusion or limitation of incidental or consequential damages, the above limitation and exclusion may not apply to you.

ALSO AVAILABLE FROM CARLON:

- Extend-A-Chime® – lets you hear your existing wired doorbell in remote areas of your home or yard
- Plug-in and Battery Doorbells and Chimes
- On/Off Remote Switches
- Touch and Automatic Lighting Controls

Carlon®

25701 Science Park Drive
Cleveland, Ohio 44122
www.lamson-sessions.com

Made in China
© 2004 LAMSON & SESSIONS
0408 IS130